













































































Finish and colours of DLS Home Audio speakers 2009-2010 models

Model	Image	White satin laquer	Black satin laquer	White piano laquer	Black piano laquer	Real wood Cherry	Real wood Black Ash	Real wood Rosewood piano	Silver	Black
M66										
M60										
D3										
DCS3										
R55 - 2009										
R50 - 2009										
RC55 - 2009										
R66 - 2009										
R60 - 2009										
T-sub8										
Q-sub8										
Q-sub 10										
Sub 3.10										
Flatbox Mini										
Flatbox Midi										
Flatbox Large										
T5										
T3										
TS3										
TM3-EFR										
TC3										
T3-LCR										
T3-LCR wide										
T3-LR	